


| No.                         | Notes | MODEL<br>COOLING CAPACITY<br>VARIATION | RP14<br>18<br>AJPNA   | RP14<br>24<br>AJPNA | RP14<br>30<br>AJPNA | RP14<br>36<br>AJPNA |
|-----------------------------|-------|----------------------------------------|-----------------------|---------------------|---------------------|---------------------|
| <b>ELECTRICAL/FAN GROUP</b> |       |                                        |                       |                     |                     |                     |
| 20                          | Stk   | Fan Motor - Before W1017               | 51-101774-02          | 51-101774-02        | 51-101774-32        | 51-102728-19        |
| 20                          | Stk   | Fan Motor - On or after W1017          | 51-101774-52          | 51-101774-52        | 51-101774-32        | 51-102728-19        |
| 21                          | Stk   | Fan Blade                              | 70-102011-12          | 70-102011-12        | 70-101323-35        | 70-101323-30        |
| 22                          | Stk   | Contactator                            | 42-104521-05          | 42-104521-05        | 42-104521-05        | 42-104521-05        |
| 23                          |       | Capacitor                              | See Compressor Group  |                     |                     |                     |
| 23a                         |       | Capacitor Strap                        | AE-104562-01          | AE-104562-01        | AE-104562-01        | AE-104562-01        |
| 24                          | Stk   | Defrost Control Board                  | 47-102685-07          | 47-102685-07        | 47-102685-07        | 47-102685-07        |
| 25                          |       | Crankcase Heater                       | See Compressor Group  |                     |                     |                     |
| 26                          |       | Grounding Lug                          | 45-19000-01           | 45-19000-01         | 45-19000-01         | 45-19000-01         |
|                             |       | Low Ambient Control                    | See Accessories Group |                     |                     |                     |
|                             |       | Low Ambient Sensor                     | 47-102709-01          | 47-102709-01        | 47-102709-01        | 47-102709-01        |
| 27                          | Stk   | Low Pressure Control                   | 47-103670-05          | 47-103670-05        | 47-103670-05        | 47-103670-05        |
| 27a                         |       | Valve Body - Low Pressure Control      | 61-18542-01           | 61-18542-01         | 61-18542-01         | 61-18542-01         |
| 28                          | Stk   | High Pressure Control                  | 47-103669-01          | 47-103669-01        | 47-103669-01        | 47-103669-01        |

| No.                         | Notes | MODEL<br>COOLING CAPACITY<br>VARIATION | RP14<br>42<br>AJPNA   | RP14<br>48<br>AJPNA | RP14<br>60<br>AJPNA |  |
|-----------------------------|-------|----------------------------------------|-----------------------|---------------------|---------------------|--|
| <b>ELECTRICAL/FAN GROUP</b> |       |                                        |                       |                     |                     |  |
| 20                          | Stk   | Fan Motor - Before W1017               | 51-101774-32          | 51-102728-13        | 51-102008-07        |  |
| 20                          | Stk   | Fan Motor - On or after W1017          | 51-101774-32          | 51-102728-24        | 51-102008-07        |  |
| 21                          | Stk   | Fan Blade                              | 70-101323-34          | 70-101323-29        | 70-101323-29        |  |
| 22                          | Stk   | Contactator                            | 42-104521-05          | 42-104521-10        | 42-104521-10        |  |
| 23                          |       | Capacitor                              | See Compressor Group  |                     |                     |  |
| 23a                         |       | Capacitor Strap                        | AE-104562-01          | AE-104562-01        | AE-104562-01        |  |
| 24                          | Stk   | Defrost Control Board                  | 47-102685-07          | 47-102685-07        | 47-102685-07        |  |
| 25                          |       | Crankcase Heater                       | See Compressor Group  |                     |                     |  |
| 26                          |       | Grounding Lug                          | 45-19000-01           | 45-19000-01         | 45-19000-01         |  |
|                             |       | Low Ambient Control                    | See Accessories Group |                     |                     |  |
|                             |       | Low Ambient Sensor                     | 47-102709-01          | 47-102709-01        | 47-102709-01        |  |
| 27                          | Stk   | Low Pressure Control                   | 47-103670-05          | 47-103670-10        | 47-103670-10        |  |
| 27a                         |       | Valve Body - Low Pressure Control      | 61-18542-01           | 61-18542-01         | 61-18542-01         |  |
| 28                          | Stk   | High Pressure Control                  | 47-103669-01          | 47-103670-10        | 47-103670-10        |  |



Exploded View